



25 FT. AIR HOSE REEL MOUNTING TEMPLATE AND INSTRUCTIONS

⚠ WARNING: Reel must be mounted to a load bearing structural member capable of supporting combined weight of the Reel, Hose, and Forces caused by pulling and maneuvering hose. Reel must be secured using (4x) 1/2" Bolts with Washers through the 4 slots in the mounting base.

1. Use 1/2" (or similar thickness) hex lag screws. The length will depend on the substrate you are going through - depending if you are going through drywall or plaster and then into the structural beam, or directly into a structural beam. (This is why hardware is not supplied as it depends on the surface.)
2. Using this template, mark the mounting bolt locations on the mounting surface.
3. Install 2 bolts with washers (without the reel) matching 2 of the "open" slots on either the top or bottom of the bolt pattern template. (Note do not tighten all the way. Leave about a 1/4" (6mm) gap from the washer to surface to allow for the mounting plate thickness.)
4. Position the reel in place by sliding onto the pre-mounted bolts and then tighten the bolts to the reel.
5. Secure the additional 2 bolts and washers in the "open" slots and tighten to the reel.

Please call 800-681-3791 for additional mounting questions.

